


Refer to IV5 series Users Manual for general functions. This manual only describes functions for Elevator I/O board. To make use of elevator functions, install EL-I/O (Elevator-dedicated I/O) board onto the IV5 inverter.

## 1 Installation and wiring

### 1.1 Terminal wiring block diagram

- SV055, 075, 110, 150, 185, 220IV5-2(DB)
- SV055, 075, 110, 150, 185, 220IV5-4(DB)




Note) ● : Power terminal, ○ : Control terminal

1) Values defined as Multi-function input terminals P1 ~ P7 are factory defaults. Battery operation is in preparation.

## SV300, 370iV5-2

SV300, 370, 450, 550, 750, 900, 1100, 1320, 1600, 2200iV5-4




Note) ● : Power terminal, ○ : Control terminal

1) Values defined as Multi-function input terminals P1 ~ P7 are factory defaults. Battery operation is in preparation.

## 1.2 Control terminal – Standard I/O Board and Elevator I/O board (EL-I/O)

### 1) Standard I/O Board terminal layout



### 2) Standard I/O Board terminal description


|               | Code    | Function                         | Description   |
|---------------|---------|----------------------------------|---|
| Contact input | FX      | Forward RUN /Stop command        | <ul style="list-style-type: none"> <li>Forward/Reverse RUN Command is ON when closed to CM separately.</li> </ul>   |
|               | RX      | Reverse RUN / Stop command       | <ul style="list-style-type: none"> <li>Motor stops when FX/RX is ON or OFF at the same time.</li> </ul>   |
|               | BX      | Emergency stop                   | ON when closed to CM, FREERUN Stop and Deceleration Stop. It does not trigger fault alarm signal.   |
|               | RST     | Fault reset                      | Resets when fault condition is cancelled.   |
|               | P1(MM0) | Multi-function input terminals   | <ul style="list-style-type: none"> <li>Elevator mode- the following 7 functions added to vector mode functions.</li> </ul> <p>Manual operation mode 0/1 (MM0, MM1), Auto operation mode (ATO), Floor Height Measuring (FHM), Operation using Battery (BAT)<sup>(1)</sup>, Brake relay input (BRC), contactor relay input(MCC)</p> <ul style="list-style-type: none"> <li>Operation using Battery function (BAT) is in preparation.</li> </ul>   |
|               | P2(MM1) |                                  |   |
|               | P3(ATO) |                                  |   |
|               | P4(FHM) |                                  |   |
|               | P5(BAT) |                                  |   |
|               | P6(BRC) |                                  |   |
|               | P7(MCC) |                                  |   |
|               | CM      | COMMON                           | <ul style="list-style-type: none"> <li>ON when each contact is closed to CM.</li> </ul>   |
| Analog input  | VREF    | Power Supply for analog setting  | <ul style="list-style-type: none"> <li>Reference voltage by variable resistor (+ 10V): 10kΩ</li> </ul>  |
|               | AI1     | Voltage/current input            | <ul style="list-style-type: none"> <li>Voltage (-10 ~ 10V) or current signal mode can be selected for the multi-function analog input. Selectable among following 8 different functions.</li> <li>(Speed/Torque/Flux command, Torque bias, Torque limit, Process PI controller command, Process controller feedback value, Draw command)</li> <li>Jumper setting in voltage signal mode ( AI1 and AI2 Open)</li> <li>Jumper setting in current signal mode ( AI1 and AI2 Closed)</li> </ul> |
|               | AI2     |                                  |   |
|               | AI3     | Voltage input<br>Motor NTC input | <ul style="list-style-type: none"> <li>Selectable for voltage and motor NTC signal (Only for LG Otis Motor)</li> <li>Jumper setting ( AI3 Open: Voltage signal ( AI3 Closed: Motor NTC signal</li> </ul>  |

|  |    |        |                           |
|--|----|--------|---------------------------|
|  | 5G | COMMON | ● COMMON for analog input |
|--|----|--------|---------------------------|


|                     | Code | Function                                    | Description  |
|---------------------|------|---|--|
| Pulse Encoder Input | PE   | Power Supply for Pulse Encoder              | +5V  |
|                     | 5G   |   | 0V   |
|                     | A+   | Encoder A phase                             | <ul style="list-style-type: none"><li>● A, B signal in Line Drive type Pulse Encoder</li><li>● Jumper JP2 on the I/O PCB should be tied to P5, Jumper JP1 to LD, respectively.</li></ul>   |
|                     | A-   |   |  |
|                     | B+   | Encoder B phase                             |  |
|                     | B-   |   |  |
|                     | PE   | Power Supply for Pulse Encoder              | +15V   |
|                     | 5G   |   | 0V   |
|                     | PA   | Encoder A phase                             | <ul style="list-style-type: none"><li>● A, B signal in Complementary or Open Collector type Pulse Encoder.</li><li>Jumper JP2 on the I/O PCB should be tied to P15, Jumper JP1 to OC, respectively.</li></ul>  |
|                     | PB   | Encoder B phase                             |  |
| Encoder output      | RA   | A phase encoder pulse output                | Encoder A, B phase signal output – Open Collector Type   |
|                     | GE   | Output Common                               |  |
|                     | RB   | B phase encoder pulse output                |  |
|                     | GE   | Output Common                               |  |
| Analog Output       | AO1  | Analog output 1                             | <ul style="list-style-type: none"><li>● -10V ~ +10V</li><li>● Selectable among 31 different functions (Motor speed, Speed command1~2, Torque command1~2, Torque current, Flux command, Flux current, Output current, Output voltage, Motor temperature, DC Voltage.. )</li></ul>   |
|                     | AO2  | Analog output 2                             |  |
|                     | 5G   | COMMON                                      | <ul style="list-style-type: none"><li>● COMMON for analog output</li></ul>   |
| Contact Output      | 1A   | Multi-function Contact output 1 (a contact) | <ul style="list-style-type: none"><li>● Selectable among the following 14 functions<br/>Zero speed detect, Speed detect (Bi-directional), Speed detect (Uni-directional), Speed reach, Speed deviation, Torque detect, On torque limit, Motor overheat, Inverter overheat, On low voltage, Inverter running, Inverter regenerating, Inverter Ready, Timer output</li></ul> |
|                     | 1B   |   |  |
|                     | 2A   | Multi-function Contact output 2 (a contact) |  |
|                     | 2B   |   |  |
|                     | OC1  | Multi-function Open Collector output        |  |
|                     | EG   |   |  |
|                     | 30A  | Fault alarm, A contact                      | <ul style="list-style-type: none"><li>● Activated when fault occurs.</li><li>● Not activated in case of emergency stop</li></ul>   |
|                     | 30B  | Fault alarm, B contact                      |  |
|                     | 30C  | COMMON                                      | <ul style="list-style-type: none"><li>● COMMON for contact A and B</li></ul>   |

3) Elevator I/O board (EL-I/O) terminal layout

■ EL-I/O version: V2.0



■ EL-I/O version: V3.0




## 4) Elevator I/O board (EL-I/O) function description

|                               | Code                              | Function   | Description   |      |      |      |      |      |     |     |     |     |     |
|-------------------------------|-----------------------------------|--|---|------|------|------|------|------|-----|-----|-----|-----|-----|
| Elevator contact input (CN3)  | I_D                               | Signal for lower Inductor  | Lower inductor signal for detecting car position  |      |      |      |      |      |     |     |     |     |     |
|                               | I_U                               | Signal for upper Inductor  | Upper inductor signal for detecting Car position  |      |      |      |      |      |     |     |     |     |     |
|                               | DLS                               | Down Limit Switch  | Switch for limiting car down operation. Down operation is disabled when this switch turns ON.   |      |      |      |      |      |     |     |     |     |     |
|                               | ULS                               | Up Limit Switch  | Switch for limiting car up operation. Up operation is disabled when this switch turns ON.   |      |      |      |      |      |     |     |     |     |     |
|                               | RV1                               | Reserved   | “WD1” in EL_IO version V2.0.  |      |      |      |      |      |     |     |     |     |     |
|                               | RV2                               | Reserved   | “WD2” in EL_IO version V2.0.  |      |      |      |      |      |     |     |     |     |     |
|                               | SD1                               | Slow Down Switch Down 1  | 1 <sup>st</sup> Down Slow-down Switch for forced deceleration   |      |      |      |      |      |     |     |     |     |     |
|                               | SU1                               | Slow Down Switch Up 1  | 1 <sup>st</sup> UP Slow-down Switch for forced deceleration   |      |      |      |      |      |     |     |     |     |     |
|                               | SD2                               | Slow Down Switch Down 2  | 2 <sup>nd</sup> Down Slow-down Switch for forced deceleration   |      |      |      |      |      |     |     |     |     |     |
|                               | SU2                               | Slow Down Switch Up 2  | 2 <sup>nd</sup> UP Slow-down Switch for forced deceleration   |      |      |      |      |      |     |     |     |     |     |
|                               | DAC                               | Decel Allowance Command  | Acknowledging signal for deceleration   |      |      |      |      |      |     |     |     |     |     |
|                               | RV3                               | Reserved   | “ACR” in EL_IO V2.0.  |      |      |      |      |      |     |     |     |     |     |
|                               | G24                               | COMMON   | ON when each contact input and G24 is connected.  |      |      |      |      |      |     |     |     |     |     |
|                               | G24                               |  |   |      |      |      |      |      |     |     |     |     |     |
| Elevator contact output (CN4) | G24OUT                            | COMMON   | Common for contact outputs  |      |      |      |      |      |     |     |     |     |     |
|                               | FS0                               | Floor Stop request /Current floor bit 0                              | <div>● Floor Stop request /Current floor data format (1~32nd)</div> <table><tr><td>Bit4</td><td>Bit3</td><td>Bit2</td><td>Bit1</td><td>Bit0</td></tr><tr><td>FS4</td><td>FS3</td><td>FS2</td><td>FS1</td><td>FS0</td></tr></table> <div>1<sup>st</sup> floor :   OFF   OFF   OFF   OFF   OFF</div> <div>32<sup>nd</sup> floor:   ON    ON    ON    ON    ON</div> | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 | FS4 | FS3 | FS2 | FS1 | FS0 |
|                               | Bit4                              | Bit3   |   | Bit2 | Bit1 | Bit0 |      |      |     |     |     |     |     |
|                               | FS4                               | FS3  |   | FS2  | FS1  | FS0  |      |      |     |     |     |     |     |
|                               | FS1                               | Floor Stop request/ Current floor bit 1                              |   |      |      |      |      |      |     |     |     |     |     |
|                               | FS2                               | Floor Stop/ Current floor bit 2                                      |   |      |      |      |      |      |     |     |     |     |     |
|                               | FS3                               | Floor Stop request / Current floor bit 3                             |   |      |      |      |      |      |     |     |     |     |     |
|                               | FS4                               | Floor Stop request / Current floor bit 4                             |   |      |      |      |      |      |     |     |     |     |     |
|                               | DER                               | Decel request signal   | Car controller releases DAC signal when this signal comes in and stop request floor and hall call floor matches.  |      |      |      |      |      |     |     |     |     |     |
|                               | FID                               | Floor Identification signal  | ON : Advance floor<br>OFF : Current floor   |      |      |      |      |      |     |     |     |     |     |
|                               | UND                               | Signal during decel  | ON when motor is in deceleration.   |      |      |      |      |      |     |     |     |     |     |
|                               | MCA/MCB                           | Contactor drive relay A contact                                      | Drives magnetic contactor in the inverter output  |      |      |      |      |      |     |     |     |     |     |
| BRA/BRB                       | A contact for Brake driving relay | Drives magnetic contactor for magnetic brake on the traction machine |   |      |      |      |      |      |     |     |     |     |     |

2 Getting started

2.1 Changing to Elevator mode

Set CON\_02 (Application) to “Elevator” after I/O option card for Elevator (E/L-I/O Card) is installed. Then, LCD window is displayed as shown below. Refer to Chapter 4, keypad for detailed key configuration.



1) Programming Elevator mode

CON Application  
02 General Vect

Move to Application mode in CON group.  
(CON\_02 can set and displayed only when Elevator I/O card installed.)

CON Application  
02 General Vect

Press the [PROG] key.  
General Vector mode ( ) will be displayed.

CON Application  
02 Elevator


Set to Elevator mode using the [ (Up)] key.

CON Application  
02 Elevator

Press the [ENT] key to finish.

2.2 LCD display

## 1) Initial display



It is called “ initial display of Display group” or “ initial display” and goes back to it by pressing SHIFT/ESC key. See the following table for details.

|   | items  | Description  |
|---|--|--|
| 1 | Elevator car position and speed (settable in E/L_58) | m/m: car speed per minute, m/s: car speed per second<br>rpm: motor actual rotating speed<br>mm: car position at present<br>motor output torque, limit switch status,<br>Remain distance when 1 <sup>st</sup> inductor (upper) is activated |
| 2 | Elevator operation mode                              | E/L: Auto operation mode<br>MAN: Manual operation mode<br>FHM: Floor Height Measurement operation mode<br>N/A: Operation mode not applied (disabled)   |
| 3 | Current car operating direction                      | UP: car operating Upward<br>DN: car operating Downward<br>STP: car at a stop   |
| 4 | Current floor (F)                                    | Current floor displayed  |
| 5 | Inverter output current (A)                          | Current flowing into motor displayed   |

## 2.3 Changing parameter group

Elevator (E/L) group is added below User group when selected.

| Groups       | LCD display (up left side of LCD) | Description   |
|--------------|-----------------------------------|---|
| Display      | DIS                               | Motor rpm, motor control mode, output torque, inverter output current, User select display, Process PID output / Ref / Fdb, current fault display, User group display select. |
| Input/output | I/O                               | Digital input parameter, Digital output parameter, Analog input parameter, Analog output parameter  |
| Parameter    | PAR                               | Parameter initialization, parameter READ / WRITE / LOCK / PASSWORD, Motor parameters, Auto tuning etc.  |
| Function     | FUN                               | Operating frequency, operating method, stopping method, electronic thermal selectable   |
| Control      | CON                               | Control mode, ASR PI Gain, Process PID Gain, Draw Control, Droop/ Torque/ V/F control parameters  |
| User         | USR                               | User macro define, User macro save, User macro recall   |
| <b>E/L</b>   | <b>E/L</b>                        | <b>Elevator speed pattern and parameter setting for position control</b>  |

- Refer to Chapter 6. Function description except E/L group.



## 2.4 Motor parameter input

Set the motor parameters as shown below before performing Auto-tuning operation to ensure the optimal control characteristic of the traction motor.

| Keypad display                     | Description  |
|------------------------------------|--|
| <div>PAR 07 Motor select kW</div>  | Enter the motor capacity. Basically it is same as inverter capacity. If no match is found, select "User Define" in PAR_07 and enter the rating in PAR_08 directly. . |
| <div>PAR 08 UserMotorSel kW</div>  | In case of selecting "User Define" in PAR_07, set the motor rating in this code directly.  |
| <div>PAR 10 Enc Pulse [][][]</div> | Set the pulse numbers per revolution of pulse encoder coupled to the motor shaft.  |
| <div>PAR 17 Base Speed rpm</div>   | Set the motor base speed.<br>Note : it is not the rated speed written on the motor nameplate.  |
| <div>PAR 18 Rated Volt V</div>     | Set the rated voltage of the motor.<br>(Voltage value on the name plate)   |
| <div>PAR 19 Pole number []</div>   | Set the number of poles of the motor.  |
| <div>PAR 20 Efficiency %</div>     | Set the efficiency of the motor. <b>If this is not found on the nameplate, do not change the initial value.</b>  |
| <div>PAR 21 Rated-Slip rpm</div>   | Set the rated slip speed of the motor.<br>Rated slip = synchronous speed – rated speed   |
| <div>PAR 22 Rated-Curr A</div>     | Set the rated current of the motor.  |

## 2.5 Auto-Tuning

Parameters such as stator resistance ( $R_s$ ), stator leakage inductance ( $sL$ ), flux current ( $I_F$ ), rotor time constant ( $\tau_r$ ) and stator self-inductance ( $L_s$ ) are indispensable for obtaining an excellent control performance in the vector control and are automatically measured keeping the motor at standstill.

### 1) Before starting

Be sure to turn the machine brake off to hold the motor shaft tightly.

### 2) Auto-tuning procedure

| Keypad display                           | Description  |
|--|--|
| PAR 23    AutoTuneType<br>StandStill     | Set the auto-tuning type to " <b>Standstill</b> ".   |
| PAR 24    Auto tuning<br>ALL1            | Auto-tuning starts if <b>ALL1</b> is set.  |
| PAR 24    Auto tuning<br>Rs Tuning       | Stator resistance ( $R_s$ ) is measured without rotating the motor.  |
| PAR 24    Auto tuning<br>sL Tuning       | The leakage inductance ( $sL$ ) is measured without rotating the motor.  |
| PAR 24    Auto tuning<br>If/Tr/Ls Tuning | Flux current ( $I_F$ ), rotor time constant ( $\tau_r$ ) and stator self-inductance ( $L_s$ ) is measured simultaneously without rotating the motor.   |
| PAR 24    Auto tuning<br>None            | When auto-tuning is completed successfully, "None" is displayed. If error occurs during auto-tuning, "[ ] Error" is displayed. In this case, verify motor parameters and encoder setting is done properly and retry the auto-tuning. If the problem continues, contact LG representative nearest to you. |
| PAR 24    Auto tuning<br>[ ] Error       |  |

### 2.6 Elevator parameter setting (In the case of 1500rpm, 120m/min, 32nd floor)

#### 1) Enter total floor number

Enter the total number of floors including ground floor which car plate is installed.

| E / L | Floor Number |
|-------|--------------|
| 0 2   | 3 2 F        |

#### 2) Elevator rated speed Input

| E / L | Car Speed   |
|-------|-------------|
| 0 3   | 1 2 0 m / m |

#### 3) Motor rated rpm input

Enters motor rpm when a car is running at E/L\_03.

| E / L | Motor Speed |
|-------|-------------|
| 0 4   | 1 5 0 0 rpm |

### 2.7 Operating mode and Multi-function relay output setting

Changing Elevator operating modes (High speed /Manual/FHM operation) are available using Multi-function input terminals. **The terminal functions should be defined based on the connection of MM0/P1, MM1/P2, ATO/P3, FHM/P4 to select elevator operating modes.**

| I / O | P1 define    |
|-------|--------------|
| 0 1   | Manual Spd-L |

| I / O | P2 define    |
|-------|--------------|
| 0 2   | Manual Spd-H |

| I / O | P3 define    |
|-------|--------------|
| 0 3   | HighSpeedRun |

| I / O | P4 define |
|-------|-----------|
| 0 4   | FHM Run   |

## Elevator application

After terminal definition is finished, operating modes are determined based on P1-P4 input status as shown below. If two input modes are assigned at the same time, latter one is ignored. If FHM mode is input during Manual mode, it is replaced by FHM mode. However, if terminal definition is done but not signal assignment and the vice versa, LCD window will display 'N/A' and STOP/RESET LED (RED) will blink, operation will be disabled.

| P1  | P2  | P3  | P4  | Operation      | LCD display |
|-----|-----|-----|-----|----------------|-------------|
| ON  | OFF | OFF | OFF | Manual         | MAN         |
| OFF | ON  | OFF | OFF | Manual         | MAN         |
| ON  | ON  | OFF | OFF | Manual         | MAN         |
| OFF | OFF | ON  | OFF | Auto(High spd) | E/L         |
| OFF | OFF | OFF | ON  | FHM            | FHM         |
| OFF | OFF | OFF | OFF | NO MODE        | N/A         |


If one of AX1, AX2 is set to "RUN", it can be used as Machine brake ON/OFF signal.

|       |            |    |       |            |
|-------|------------|----|-------|------------|
| I / O | AX1 define | Or | I / O | AX2 define |
| 4 1   | Run        |    | 4 2   | Run        |

### 2.8 Checking Encoder In Manual operation

#### 1) UP direction rotating

Up direction means elevator car goes UP when FX input terminal is ON.



#### 2) Parameter setting for control terminal operation - Ex) 15m/min Manual operation

Check the settings in the following table before starting Low Speed Manual Operation and input status of multi-function input terminals. (Refer to 6.1)

| MF input terminal \ Description | Defining input terminal function | Input value from operation controller |
|---------------------------------|----------------------------------|---------------------------------------|
| MM0/P1                          | Manual Spd-L                     | ON                                    |
| MM1/P2                          | Manual Spd-H                     | OFF                                   |

## ◆ Moving to FUN group

**FUN Run/Stop Src**  
**01 Terminal 1**

RUN/STOP command via control terminal  
(“Err – CMDSRC” will appear when setting via Keypad and operation unavailable.)

**FUN Spd Ref Sel**  
**02 Keypad1**

Speed ref. selection via Keypad

## ◆ Moving to E/L group

**E/L Manual Spd1**  
**22 15.0 m/m**

Operating speed setting

## 3) UP /DOWN direction operation

Low Speed Manual operation

- Press the [UP] button and check if motor speed in initial display of Display group is 15m/m and direction “UP”. Floor height is displayed as “—F” before FHM operation.

**15.0m/m MAN**  
**UP --F 4.6A**

- Press the [DOWN] button and check if motor speed in initial display of Display group is 15m/m and direction “DN”.

**15.0m/m MAN**  
**DN --F 4.6A**

Operating state in the case of reverse wiring of encoder and motor is as follows;

| FX/RX | Car direction | Speed display    | Torque display <sup>1)</sup> | Operation status                |
|-------|---------------|------------------|------------------------------|---------------------------------|
| FWD   | UP            | +15.0 m/m        | Over -10%                    | Normal                          |
| REV   | DOWN          | -15.0 m/m        | Over -10%                    |                                 |
| FWD   | UP            | -4.5 ~ 10.5 m/m  | 150%                         | Encoder wiring reversed         |
| REV   | DOWN          | 4.5 ~ 10.5 m/m   | -150%                        |                                 |
| FWD   | DOWN          | -4.5 ~ -10.5 m/m | 150%                         | Motor wiring reversed           |
| REV   | UP            | 4.5 ~ 10.5 m/m   | -150%                        |                                 |
| FWD   | DOWN          | +15.0 m/m        | Over +10%                    | Encoder / Motor wiring reversed |
| REV   | UP            | -15.0 m/m        | Over +10%                    |                                 |

1) Torque display is based on No-load low speed Manual operation. Set E/L\_58 to "Trq Output" to display torque.

- Check for the encoder wiring reversed. If so, correct the encoder wiring.


Check for the motor wiring reversed. If so, change the wiring of two phases (U,W).

- When the car operating direction on the keypad display is reversed, check whether FX/RX signal is opposite. Or if FX/RX signal is normally set but the car direction is opposite, change the motor rotating direction in (E/L\_05)".
- Check for Encoder wiring and Multi-function input terminal setting when Speed display keeps showing 0.0m/m.
- When vibration level is high during stop of manual operation due to sudden deceleration and Over voltage trip occurs, change the setting of **E/L\_31 (ManZeroDec T) to 1.0 sec.**

|            |                     |
|------------|---------------------|
| <b>E/L</b> | <b>ManZeroDec T</b> |
| <b>31</b>  | <b>1.0 sec</b>      |

### 2.9 FHM (Floor height measurement) operation

- 1) Check inductor signal and forced deceleration switch SD1 and SU1 are wired to elevator I/O board. If SU1 is not properly installed, caution should be taken because the car may not stop at the highest level automatically during FHM operation. Move the car to Lowest floor and Highest floor by manual operation to check the input of inductor and forced decel switch is properly installed. (Refer to 7.3 (46))
- 2) Move the car to the lowest floor with manual operation ON and stop the car at the position where upper inductor is within the plate and down inductor is out of the plate as shown below.



- 3) Check E/L\_02 (Floor Number) sett value matches total floors (Max. stop floor).
- 4) Change the operating mode to FHM operation by issuing ON signal to multi-function input terminal defined as this operation. If inductor position is different from the above figure or SD1 is not activated, keypad will display the message “**NOTRDY**” as shown below and STOP/RESET LED (Red) will be flickering. In this case, FHM operation cannot be activated. Return to Manual operation mode and set the inductor position correctly and check the forced deceleration switch and try FHM operation again.

|     |        |        |
|-----|--------|--------|
| E/L | 0.0m/m | FHM    |
| Err | 1F     | NOTRDY |

- 5) Apply FX signal and FHM operating command in inverter control terminal and initiate FHM operation. Keep UP operation command until car reaches the highest floor level. Car speed change is available if terminals defined as MM0, MM1 are turned ON.
  - 3) When car reaches the highest level, inverter automatically starts to decelerate and maintains the zero speed. At this time, remove the FX signal and FHM operation is finished.
- When UP/DOWN inductors signal is reversely connected to EL-I/O board, operation is stopped and fault message will appear as shown below upon the car leaving lowest floor in early stage of FHM operation. In this case, change the wiring of inductor signals. After this, return to Manual operation, move the car to the position

same as figure (page 15) and perform FHM operation again.

|            |                     |
|------------|---------------------|
| <b>DIS</b> | <b>Faults</b>       |
| <b>05</b>  | <b>IND Reversed</b> |

- After FHM operation started and plate sensing signals from UP/Down inductors are not input at the same time, the following message will appear with the operation stopped. In this case, adjust the inductor position. After this, return to manual operation and move the car as directed in page 15 and restart FHM operation.

|            |                     |
|------------|---------------------|
| <b>DIS</b> | <b>Faults</b>       |
| <b>05</b>  | <b>IND'TOR FAIL</b> |

- LCD display when FHM is completed. Current floor value becomes Highest floor (E/L\_02).

|            |               |             |
|------------|---------------|-------------|
|            | <b>0.0m/m</b> | <b>FHM</b>  |
| <b>STP</b> | <b>32F</b>    | <b>0.0A</b> |

- After finishing FHM operation, each floor height can be checked in E/L\_60 in mm.

|            |                     |
|------------|---------------------|
| <b>E/L</b> | <b>Show FlrPosi</b> |
| <b>60</b>  | <b>1F</b>           |

Press [PROG] key in E/L\_60.

|            |             |            |
|------------|-------------|------------|
| <b>E/L</b> | <b>POSI</b> | <b>0mm</b> |
| <b>60</b>  |             | <b>1F</b>  |

Increase/decrease the floor No. by pressing [UP]/[DOWN] Key.

|            |             |                |
|------------|-------------|----------------|
| <b>E/L</b> | <b>POSI</b> | <b>45000mm</b> |
| <b>60</b>  |             | <b>16F</b>     |

Accumulated floor height is displayed as floor number is increasing.

|            |             |               |
|------------|-------------|---------------|
| <b>E/L</b> | <b>POSI</b> | <b>3000mm</b> |
| <b>60</b>  |             | <b>2F</b>     |

Escape the code using [MODE] or [ENT] key when finished.



- When highest floor is reached but sensing number of UP/DOWN inductor is less than E/L\_02 or measured floor height data is incorrect, fault message will appear when removing FX signal.

|            |                     |
|------------|---------------------|
| <b>DIS</b> | <b>Faults</b>       |
| <b>05</b>  | <b>FHM Run Fail</b> |

Plate sensing number does not match E/L\_02  
(Max stop-available floor).

|            |                      |
|------------|----------------------|
| <b>DIS</b> | <b>Faults</b>        |
| <b>05</b>  | <b>Flr Data Fail</b> |

Measured floor data is wrong.

- Check plate installation, noise interference in inductor signal and inductor malfunction to correct the error. After clearing the cause, move the car to the lowest floor and retry FHM operation.
- When FHM is failed, error message will appear in the initial display if not pressing [STOP/RESET] key while fault message is output. Only pressing [MODE] key moves to initial display at fault message output ([SHIFT/ESC] deactivated).

Number of car plate sensing does not match E/L\_02 (Max stop-available floor). FHM Run Fail

|            |               |               |
|------------|---------------|---------------|
|            | <b>0.0m/m</b> | <b>FHM</b>    |
| <b>Err</b> | <b>32F</b>    | <b>Fcount</b> |

When there is a certain floor far less than below floor or distance is too close. Flr Data Fail

|            |               |              |
|------------|---------------|--------------|
|            | <b>0.0m/m</b> | <b>FHM</b>   |
| <b>Err</b> | <b>32F</b>    | <b>Fdata</b> |

- When FHM is succeeded, each floor height and its checksum save into memory. If previous Checksum data and new Checksum when power ON differ, the following error message will appear and FHM operation is required.

|            |                     |
|------------|---------------------|
| <b>DIS</b> | <b>Faults</b>       |
| <b>05</b>  | <b>Checksum Err</b> |

- Forced decel switch (SD1, SU1) position measurement – Measure SD1 installation position based on lowest floor level during FHM operation. Also, measure SU1 installation position based on highest floor level. Measured data can be checked after setting DIS\_01 ~ DIS\_03 to either “SDSD1 Posi” or “SDSU1 Posi”..

|     |            |
|-----|------------|
| DIS | SDSD1 Posi |
| 01  | 1200.0 mm  |

|     |            |
|-----|------------|
| DIS | SDSU1 Posi |
| 01  | 1200.0 mm  |

### 2.10 High speed auto operation

- High speed operation is ready to perform when FHM operation is finished successfully. However, FHM operation is stopped when the upper inductor (IND\_U) is not within a car plate so car does not begin operation when hall call is input even if E/L\_50 is set to “Inductor ON”(high speed operation active in normal condition). Therefore, high speed auto operation should be performed after setting UP/DOWN inductors within the car plate by performing manual operation.

|     |              |
|-----|--------------|
| E/L | HighSpdStart |
| 50  | Inductor ON  |

- Adjustment of Speed control gain and torque limit value**

Adjust the gain for speed control and torque limit when large level error is generated at leveling to stop or car is not stable during accel/decel operation. Gain value for speed control increases if ASR P Gain1 (CON\_03) value is increases, ASR I Gain1 (CON\_04) value decreases.

Adjust the torque limit values for Pos Trq Lmt (CON\_29), Neg Trq Lmt (CON\_30), Reg Trq Lmt (CON\_31) between 160% and 180% depending on the load condition.

- Overload trip level and time setting**

Set the OLT Level (I/O\_60) between 150 and 170%, 10% less than torque limit value and OLT Time (I/O\_61) to 60 sec.

- Adjustment of operating condition at starting**

Perform one floor, two floors, three floors and highest/lowest floor operation repeatedly to check car operating condition at start, stop and during running at constant speed. Especially when sudden start shock occurs due to static friction of traction machine, adjust the set value as shown below to get a better riding comfort.

### Recommended adjusting range

|     |                      |
|-----|----------------------|
| E/L | StartUpAccel         |
| 52  | 0.01m/s <sup>2</sup> |

(0.01 ~ 0.03m/s<sup>2</sup>)

|     |             |
|-----|-------------|
| E/L | StartUpAccT |
| 53  | 0.50 sec    |

(0.3 ~ 0.8 sec)

|     |              |
|-----|--------------|
| E/L | StartUp Wait |
| 54  | 0.20 sec     |

(0.2 ~ 0.4 sec)

## 3 Display group (DIS\_[][])

### 1) DIS\_01 ~ 03 (User display select 1, 2, 3)

One of the following parameters is displayed when selected in this code.

Factory default values: **DIS\_01**= "PreRamp Ref", **DIS\_02**= "DC Bus Volt", **DIS\_03**= "Terminal In"

- When EL-I/O board is connected to the inverter control board and **CON\_02** is set to "Elevator", the followings will appear according to selection.

| Cod e                 | LCD display  | Name                                | Unit  | Description   |
|-----------------------|--------------|-------------------------------------|-------|---|
| DIS_01<br>~<br>DIS_03 | Car Speed    | Rated car speed per minute          | m/min | Current Car speed displayed in "m/min"  |
|                       | Car Speed    | Rated car speed per sec             | m/sec | Current Car speed displayed in "m/sec"  |
|                       | Car Position | Value of current car position       | mm    | Current Car position displayed in "mm"  |
|                       | ELIO IN      | ELIO input signal                   | -     | Inductor, limit switch, decel acknowledging signal, input terminal ON/OFF status display, '1' : Closed, '0' : Open, displayed differently between v2.0 and v3.0<br>(see the first row for ELIO v2.0 and second row for ELIO v3.0) |
|                       |              |                                     |       | <div> <div>LSB</div> <div>MSB</div> </div>  |
|                       |              |                                     |       | <div> <div>I_D</div> <div>I_U</div> <div>DLS</div> <div>ULS</div> <div>WD1</div> <div>WD2</div> <div>SD1</div> <div>SU1</div> <div>SD2</div> <div>SU2</div> <div>DAC</div> <div>ACR</div> </div>                                  |
|                       |              |                                     |       | <div> <div>I_D</div> <div>I_U</div> <div>DLS</div> <div>ULS</div> <div>RV1</div> <div>RV2</div> <div>SD1</div> <div>SU1</div> <div>SD2</div> <div>SU2</div> <div>DAC</div> <div>RV3</div> </div>                                  |
|                       | Limit S/W In | Limit switch status                 | -     | ON/OFF switch status display considering E/L_40 ELIO IN A or B contact, '1': S/W ON, '0': S/W OFF, bit meaning is the same as ELIO IN.  |
|                       | ELIO Out     | ELIO output signal                  | -     | Floor info (current floor, forward going floor), floor indication, decel request, decelerating, contactor driving, brake signal ON/OFF status displayed   |
|                       |              |                                     |       | <div> <div>LSB</div> <div>MSB</div> </div>  |
|                       |              |                                     |       | <div> <div>FS0 FS1 FS2 FS3 FS4</div> <div>DER</div> <div>FID</div> <div>UND</div> <div>MC</div> <div>BR</div> </div>  |
|                       | Tuning Dist  | Tuning distance                     | mm    | Remaining distance when 1 <sup>st</sup> inductor is operating (UP: IN_U, Down: IN_D)  |
|                       | Cur Floor    | Current floor                       | F     | Floor value where elevator car is located.  |
|                       | Adv Floor    | Stop-available floor                | F     | Floor where the elevator car can stop at.   |
|                       | Remain Dist  | Remain distance                     | mm    | Remain distance to target floor level after deceleration.   |
|                       | SDS1 Speed   | 1 <sup>st</sup> SDSD (Up) car speed | m/m   | Displays car speed in m/m when SDSD1 (negative value) or SDSU1 (positive value) operates.   |
|                       | SDS2 Speed   | 2 <sup>nd</sup> SDSD (Up) car speed | m/m   | Displays car speed in m/m when SDSD2 (negative value) or SDSU2 (positive value) operates.   |
|                       | SDS3 Speed   | 3 <sup>rd</sup> SDSD (Up) car speed | m/m   | Displays car speed in m/m when SDSD3 or SDSU3 operates. (in preparation).   |
|                       | Min.FlrDist  | Floor distance Minimum              | mm    | Indicates minimum distance of the floors in the building.   |
|                       | Min.RunDist  | Minimum running distance            | mm    | Distance required to make starting and ending pattern of acceleration   |
|                       | DecelDist    | Rated Decel distance                | mm    | Distance required to decelerate from car rated speed.   |
|                       | Min.SpdAcc   | Min. speed for acceleration end     | m/m   | Min. speed required to make start and end pattern of acceleration   |
|                       | Min.SpdDec   | Min. speed for deceleration start   | m/m   | Min. speed required to make start and end pattern of deceleration   |
|                       | Dec.End Dist | Distance for deceleration end       | mm    | Distance required to make end pattern of deceleration.  |
|                       | SDSD1 Dist   | 1 <sup>st</sup> SDSD distance       | mm    | Distance between the lowest level and SDSD1 installation position.  |
|                       | SDSU1 Dist   | 1 <sup>st</sup> SDSU distance       | mm    | Distance between the highest level and SDSU1 installation position.   |
|                       | SDSD2 Dist   | 2 <sup>nd</sup> SDSD distance       | mm    | Distance between the lowest level and SDSD2 installation position.  |

|  |            |                               |    |   |
|--|------------|-------------------------------|----|---|
|  | SDSU2 Dist | 2 <sup>nd</sup> SDSU distance | mm | Distance between the highest level and SDSU2 installation position.                 |
|  | SDSD3 Dist | 3 <sup>rd</sup> SDSD distance | mm | Distance between the lowest level and SDSD3 installation position (in preparation)  |
|  | SDSU3 Dist | 3 <sup>rd</sup> SDSU distance | mm | Distance between the highest level and SDSU3 installation position (in preparation) |

### 2) DIS\_05 (Fault status display)

Current fault status/ previous fault history (1,2) / number of previous faults/ clear previous faults are displayed. Use [SHIFT/ESC] key to navigate these functions in DIS\_05.

| Code   | LCD display | Name                            | Description   |
|--------|-------------|---------------------------------|---|
| DIS_05 | Faults      | Fault status display            | <b>No Fault</b> displayed during normal operation. Faults status is displayed when faults occur. (Refer to '[3]' fault display) |
|        | Last Fault1 | Previous fault display          | <b>Refer to troubleshooting.</b>  |
|        | Last Fault2 | Previous previous fault display |   |
|        | Fault Count | Total number of faults          | Display total number of faults occurred.  |
|        | Fault Clear | Clearing faults number          | Resets total number of faults to 0.   |

Fault contents, speed reference at the time of fault, speed feedback, output frequency/current/voltage, torque current reference value and actual value, DC link voltage, input terminal status, output terminal status, operating status, run time can be check using [PROG], [ (Up)] / [ (Down)] keys before pressing [RESET] key. Pressing [ENT] key returns to first. Pressing [RESET] key saves data into Last Fault 1. Refer to [Chapter 8 Troubleshooting and maintenance].

| No | Fault status          | Keypad display | No | Fault status                                       | Keypad display      |
|----|-----------------------|----------------|----|--|---------------------|
| 1  | Over current- phase U | OC-U           | 13 | Inverter Overheat                                  | Inv OverHeat        |
| 2  | Over current- phase V | OC-V           | 14 | Electronic thermal                                 | E-Thermal           |
| 3  | Over current- phase W | OC-W           | 15 | Overload trip                                      | Over Load           |
| 4  | Fuse open             | Fuse Open      | 16 | External trip input B                              | Ext-B Trip          |
| 5  | Over voltage          | Over Voltage   | 17 | Option error                                       | Option Err          |
| 6  | IGBT short- phase U   | Arm Short-U    | 18 | Inverter overload                                  | Inv OLT             |
| 7  | IGBT short- phase V   | Arm Short-V    | 19 | Motor overheat                                     | Mot OverHeat        |
| 8  | IGBT short- phase W   | Arm Short-W    | 20 | Inverter thermal open                              | Inv THR Open        |
| 9  | IGBT short- phase DB  | Arm Short-DB   | 21 | Motor thermal open                                 | Mot THR Open        |
| 10 | Encoder error         | Encoder Err    | 22 | Motor overspeed                                    | Over Speed          |
| 11 | Low voltage           | Low Voltage    | 23 | <b>Floor height measurement data<sup>(1)</sup></b> | <b>Flr/FHM Data</b> |
| 12 | Ground fault          | Ground Fault   | 24 | <b>Slow down switch error<sup>(1)</sup></b>        | <b>SDS Error</b>    |

**(1) detection is available only when elevator board is installed.**

**Note :** when multiple faults occur, latest fault is displayed and others can be checked in previous fault display.

### 4 I/O group (I/O\_[][])

#### 1) I/O\_01 ~ 07 (Multi-function Input terminals P1~7 define)

When EL-I/O board is connected to the inverter control board and CON\_02 is set to “Elevator”, the following functions can be selected in I/O\_01 ~ 07.

| Code                  | LCD display    | Name                                     | Description  |
|-----------------------|----------------|--|--|
| I/O_01<br>~<br>I/O_07 | Manual Spd-L   | Manual low speed operation command bit 0 | Three kinds of speeds can be selected with mixture of manual low speed operation command bit 0 and bit 1.  |
|                       | Manual Spd-H   | Manual low speed operation command bit 1 |  |
|                       | HighSpeed Run  | High speed operation Run command         | Selects High speed auto run command  |
|                       | FHM Run        | Floor height measurement run command     | Selects FHM run command  |
|                       | BaseFloor Run  | Base floor run command                   | Select this command to compensate the car position by performing lowest floor operation when power failure or emergency stop occurs during high speed auto operation.  |
|                       | NearFloor Run  | Nearest floor run command                | Use this command to rescue passengers by operating car to nearest floor when power failure or emergency stop occurs during high speed auto operation.  |
|                       | MotorM/C State | Motor output contactor relay input       | A contact input for checking contactor driving state when contactor is installed between inverter and motor. Operation will not be allowed when there is no contact input even though this function is set to use. |
|                       | CarBrake State | Brake contact input                      | Brake driving relay or brake contact input for Brake driving state check. Operation will not be allowed when there is no contact input even though this function is set to use.                                    |

## 5 Function code table for Elevator group (E/L\_□□)

| CODE NO. | CODE NAME  | LCD DISPLAY   | SETTING DATA                  |                    |              | Adj. During Run <sup>(6)</sup> | Page |
|----------|--|---------------|-------------------------------|--------------------|--------------|--------------------------------|------|
|          |  |               | RANGE                         | UNIT               | DEFAULT      |                                |      |
| E/L_00   | Jump Code  | Jump Code     | 1 ~ 60                        |                    |              |                                | 22   |
| E/L_01   | Speed Reference pattern select                               | Spd Ref Type  | DecelReq-D/B<br>DecelReq-T/B  |                    | DecelReq-D/B | No                             | 22   |
| E/L_02   | Number of total floor  | Floor Number  | 1 ~ 32                        | FLOOR              | 32           | No                             | 23   |
| E/L_03   | Rated car speed  | Car Speed     | 30 ~ 420                      | m/m                | 60           | No                             | 23   |
| E/L_04   | Motor speed at rated car speed                               | Motor Speed   | 20.0 ~ 3600.0                 | rpm                | 1500.0       | No                             | 23   |
| E/L_05   | Motor rotating direction select                              | UP Direction  | FX-CCW<br>FX-CW               |                    | FX-CCW       | No                             | 23   |
| E/L_06   | Rated acceleration speed                                     | Rated Accel   | 0.10 ~ 1.00                   | m/sec <sup>2</sup> | 0.50         | No                             | 24   |
| E/L_07   | Rated deceleration speed                                     | Rated Decel   | 0.10 ~ 1.00                   | m/sec <sup>2</sup> | 0.50         | No                             | 24   |
| E/L_08   | Acceleration start time                                      | Acc Start T   | 0.50 ~ 2.50                   | sec                | 1.00         | No                             | 24   |
| E/L_09   | Acceleration end time  | Acc End T     | 0.50 ~ 2.50                   | Sec                | 1.00         | No                             | 24   |
| E/L_10   | Deceleration start time                                      | Dec Start T   | 0.50 ~ 2.50                   | sec                | 1.00         | No                             | 24   |
| E/L_11   | Deceleration end time  | Dec End T     | 0.50 ~ 2.50                   | sec                | 1.00         | No                             | 24   |
| E/L_12   | Communication delay compensation distance                    | CommDlyDist   | 100 ~ 1000                    | mm                 | 400          | No                             | 25   |
| E/L_13   | Deceleration start adjustment                                | DecStart Adj  | -10 ~ 100                     | mm                 | 0            | No                             | 25   |
| E/L_14   | Pre-excitation time  | PreExt Time   | 100 ~ 10000                   | msec               | 300          | No                             | 25   |
| E/L_15   | Brake open time  | Brake Time    | 0 ~ 10000                     | msec               | 300          | No                             | 25   |
| E/L_16   | Hold time  | Hold Time     | 0 ~ 10000                     | msec               | 300          | No                             | 25   |
| E/L_17   | Wait time before Restart                                     | Restart Time  | 1.00~100.00                   | sec                | 1.00         | No                             | 25   |
| E/L_18   | Plate length   | Plate Length  | E/L_19~1000.0                 | mm                 | 200.0        | Yes                            | 26   |
| E/L_19   | Distance between inductor and top plate                      | InductorEdge  | 0.0 ~ E/L_18                  | mm                 | 20.0         | Yes                            | 26   |
| E/L_20   | Car speed during FHM (Floor height measurement) operation    | FHM/BFR Speed | 0.0 ~ 60.0                    | m/m                | 15.0         | No                             | 27   |
| E/L_21   | Floor height measurement data                                | FHM DATA      | 0 ~ 321                       |                    | 0            | Yes                            | 27   |
| E/L_22   | Car speed 1 during manual operation                          | Manual Spd1   | 0.0 ~ 60.0                    | m/m                | 3.0          | No                             | 27   |
| E/L_23   | Car speed 2 during manual operation                          | Manual Spd2   | 0.0 ~ 60.0                    | m/m                | 10.0         | No                             | 27   |
| E/L_24   | Car speed 3 during manual operation                          | Manual Spd3   | 0.0 ~ 60.0                    | m/m                | 15.0         | No                             | 27   |
| E/L_25   | Acceleration speed during manual operation                   | MAN Accel.    | 0.01 ~ 5.00                   | m/sec <sup>2</sup> | 0.25         | No                             | 28   |
| E/L_26   | Deceleration speed during manual operation                   | MAN Decel.    | 0.01 ~ 5.00                   | m/sec <sup>2</sup> | 0.25         | No                             | 28   |
| E/L_27   | Acceleration start time during manual operation              | ManAccStartT  | 0.01 ~ 2.00                   | sec                | 0.50         | No                             | 28   |
| E/L_28   | Acceleration end time during manual operation                | Man AccEnd T  | 0.01 ~ 2.00                   | sec                | 0.50         | No                             | 28   |
| E/L_29   | Deceleration start time during manual operation              | ManDecStartT  | 0.01 ~ 2.00                   | sec                | 0.50         | No                             | 28   |
| E/L_30   | Deceleration end time during manual operation                | Man DecEnd T  | 0.01 ~ 2.00                   | sec                | 0.50         | No                             | 28   |
| E/L_31   | Deceleration time during manual operation                    | ManZero Dec T | 0.00 ~ 600.00                 | sec                | 2.00         | No                             | 29   |
| E/L_32   | Distance compensation, Minimum during operation              | DistComp.Min  | 0.0 ~ 2"E/L_19                | mm                 | 0.0          | No                             | 29   |
| E/L_33   | Distance compensation, Maximum during operation              | DistComp.Max  | 0.0 ~ 100.0                   | mm                 | 0.0          | No                             | 29   |
| E/L_34   | Leveling distance compensation <sup>(1)</sup>                | DistComp.Lev  | -E/L_19 ~ E/L_19              | mm                 | 0            | No                             | 29   |
| E/L_35   | Creep speed <sup>(2)</sup>                                   | Creep Speed   | 0.1 ~ 60.0                    | m/m                | 3.0          | No                             | 30   |
| E/L_36   | Creep distance <sup>(2)</sup>                                | Creep Dist.   | 0 ~ 500                       | mm                 | 5            | No                             | 30   |
| E/L_37   | Position control end and zero speed decel start distance     | D/B End Dist  | 0 ~ E/L_19                    | mm                 | 0            | No                             | 30   |
| E/L_38   | Time to decelerate to zero speed after position control ends | SpdZero Time  | 0.00 ~ 10.00                  | sec                | 2.00         | No                             | 30   |
| E/L_39   | ELIO input negative (inversion)                              | ELIO In Neg   | 000000000000<br>~111111111111 | -                  | 000000000000 | No                             | 30   |
| E/L_40   | Inductor input filter time                                   | IND Filter    | 0 ~ 50                        | ms                 | 25           | No                             | 31   |
| E/L_41   | Filter time for SDS input                                    | SDS Filter    | 50 ~ 500                      | ms                 | 250          | No                             | 31   |

| CODE NO. | CODE NAME  | LCD DISPLAY  | SETTING DATA  |                    |               | Adj. During Run <sup>(6)</sup> | Page |
|----------|--|--------------|---|--------------------|---------------|--------------------------------|------|
|          |  |              | RANGE   | UNIT               | DEFAULT       |                                |      |
| E/L_42   | Forced deceleration starting speed during SDS-1 input              | ForcedDecSpd | 0.0 ~ 420.0   | m/m                | 0.0           | No                             | 31   |
| E/L_43   | Deceleration speed during SDS-1 forced deceleration <sup>(4)</sup> | ForcedDecel  | 0.01 ~ 1.50   | m/sec <sup>2</sup> | 1.50          | No                             | 31   |
| E/L_44   | Creep speed during forced deceleration <sup>(4)</sup>              | ForcedCrpSpd | 0.0 ~ 60.0  | m/m                | 3.0           | No                             | 31   |
| E/L_45   | Wait after zero speed arrival during forced <sup>(4)</sup>         | Frcd.DecWait | 0 ~ 10000   | ms                 | 300           | No                             | 31   |
| E/L_46   | Use SDS-2  | Use FrcdDcl2 | No<br>Yes   |                    | No            | No                             | 32   |
| E/L_47   | Forced deceleration start speed during SDS-2 input <sup>(5)</sup>  | Frcd.DecSpd2 | 0.0 ~ 420.0   | m/m                | 0.0           | No                             | 32   |
| E/L_50   | Starting Condition for High speed Auto Operation                   | HighSpdStart | Inductor ON<br>Always   | -                  | Inductor ON   | No                             | 32   |
| E/L_51   | Select the acceleration curve at start-up                          | AccStartType | Linear<br>S-curve   | -                  | Linear        | No                             |      |
| E/L_52   | Start-up acceleration speed  | StartupAccel | 0.00 ~ 1.00   | m/sec <sup>2</sup> | 0.00          | No                             | 32   |
| E/L_53   | Start-up acceleration time   | StartupAccT  | 0.01 ~ 5.00   | sec                | 0.50          | No                             | 32   |
| E/L_54   | Start-up wait time   | StartupWait  | 0.00 ~ 5.00   | sec                | 0.50          | No                             | 32   |
| E/L_55   | Wait time before leveling at lowest floor/Nearest floor            | BFR/NFR Wait | 0.00 ~ 5.00   | Sec                | 0.30          | No                             | 33   |
| E/L_58   | Keypad display selection   | Display Sel. | Car Spd (m/m)<br>Car Spd (M/S)<br>Car Spd (RPM)<br>Car Position<br>Trq Output<br>Lmt.S/W State<br>Tuning Dist |                    | Car Spd (m/m) | Yes                            | 32   |
| E/L_59   | Clear car position   | Clear Posi.  | No<br>Yes   |                    | No            | No                             | 34   |
| E/L_60   | Show floor position  | Show FlrPosi | 1 ~ E/L_02  | FLOOR              | 1             | Yes                            | 34   |
| E/L_61   | Start condition for Floor Height Measurement operation             | FHM Start    | ID-OFF/IU-ON<br>DLS ON/SD1-ON   | -                  | ID-OFF/IU-ON  | No                             |      |
| E/L_62   | Keypad FHM operation set   | Keypad FHM   | No<br>Yes   |                    | No            | No                             |      |
| E/L_63   | Up direction level compensation                                    | UpDir Level  | -E/L_19~E/L_19  | mm                 | 0             | No                             |      |
| E/L_64   | Down direction level compensation                                  | DnDir Level  | -E/L_19~E/L_19  | mm                 | 0             | No                             |      |

(Note)

- 1) Only displayed when E/L\_01 is set to “DecelReq-D/B”
- 2) Only displayed when E/L\_01 is set to “DecelReq-T/B”
- 3) Only displayed when E/L\_42 is set to the value other than “0”
- 4) Only displayed when E/L\_42 or E/L\_47 is set to the value other than “0”
- 5) Only displayed when E/L\_46 is set to “Yes”
- 6) Yes: Adjsutable during run, No: not abvailable

## 6 Elevator group

### 1) Jump code

You can move on to the code you want to check using E/L\_00.

(Example) moving on to E/L\_03

After pressing the [PROG] key, set 3 using [SHIFT/ESC] / [ UP] / [ DOWN] keys and press [ENT]. The following will be displayed.

|            |                  |
|------------|------------------|
| <b>E/L</b> | <b>Car Speed</b> |
| <b>03</b>  | <b>120m/m</b>    |


You can check the other codes using [ UP] / [ DOWN] keys.

### 2) E/L\_01

In elevator speed pattern, two different speed patterns can be selected by Decel request signal before passing the floor which elevator car can stop at. These are "DecelReq-D/B" (Distance-based Decel request) and "DecelReq-T/B" (Time-based Decel request).

| Code   | LCD display  | Parameter name              | Setting range                | Unit | Factory setting |
|--------|--------------|-----------------------------|------------------------------|------|-----------------|
| E/L_01 | Spd Ref Type | Speed reference type select | DecelReq-D/B<br>DecelReq-T/B | -    | DecelReq-D/B    |


Speed pattern by "DecelReq-D/B"



When the car starts running, position controller generates advance floor ( floor at which car can be stopped with speed pattern above) signals (terminals CN4-FS0, FS1, FS2, FS3, FS4, FID on EL-I/O board). Inverter outputs Decel request signal to car controller before advance floor signals are renewed. Car controller receives signal from inverter and checks whether there is **floor to be serviced** matching advance floor signal which inverter outputs. If advance floor signal matches the floor to be serviced, car controller transmits Decel acknowledging signal (CN3-DAC terminal on the board) to the inverter and then inverter gets ready to decelerate and starts deceleration at the place which distance to target



floor matches deceleration-assuring distance and stops at the target floor with speed reference based on the remaining distance to target floor.



It is similar to "DecelReq-D/B" except that its speed pattern has a constant speed zone (creep zone) before levelling based on time.

### 3) E/L\_02 (Number of total floor, stop-available floor)

### 4) E/L\_03 (Rated car speed)

### 5) E/L\_04 (Motor speed at rated car speed)

Sets number of floors for elevator car to stop, rated car speed and motor speed when E/L\_03 is output in each parameter. Enter total floor including underground floor in E/L\_02 and motor speed in E/L\_04 when car is running according to E/L\_03.

| Code   | LCD display  | Parameter name                           | Setting range | Unit  | Factory setting |
|--------|--------------|--|---------------|-------|-----------------|
| E/L_02 | Floor Number | Number of total floor elevator car stops | 1 ~ 32        | floor | 32              |
| E/L_03 | Car Speed    | Rated car speed                          | 30 ~ 420      | m/min | 240             |
| E/L_04 | Motor Speed  | Motor speed at rated car speed           | 20.0 ~ 3600.0 | rpm   | 1500.0          |

### 6) E/L\_05

iV5 is programmed to perform UP operation when FX signal is on. But if the car performs "Down operation" when Fx is ON, set this code to FX-CW.

| Code   | LCD display  | Parameter name                  | Setting range   | Unit | Factory setting |
|--------|--------------|---------------------------------|-----------------|------|-----------------|
| E/L_05 | UP Direction | Motor rotating direction select | FX-CCW<br>FX-CW | -    | FX-CCW          |

7) E/L\_06

8) E/L\_07


9) E/L\_08

10) E/L\_09

11) E/L\_10

12) E/L\_11

| Code   | LCD display | Parameter name           | Setting range | Unit               | Factory setting |
|--------|-------------|--------------------------|---------------|--------------------|-----------------|
| E/L_06 | Rated Accel | Rated acceleration speed | 0.10 ~ 1.00   | m/sec <sup>2</sup> | 0.50            |
| E/L_07 | Rated Decel | Rated deceleration speed | 0.10 ~ 1.00   | m/sec <sup>2</sup> | 0.50            |
| E/L_08 | Acc Start T | Acceleration start time  | 0.50 ~ 2.50   | sec                | 1.00            |
| E/L_09 | Acc End T   | Acceleration end time    | 0.50 ~ 2.50   | sec                | 1.00            |
| E/L_10 | Dec Start T | Deceleration start time  | 0.50 ~ 2.50   | sec                | 1.00            |
| E/L_11 | Dec End T   | Deceleration end time    | 0.50 ~ 2.50   | sec                | 1.00            |



**13) E/L\_12**

Compensates distance which car is moving while inverter sends decel request signal to car controller and receives decel acknowledging signal. This value is used to calculate stop request floor.

| Code   | LCD display | Parameter name                           | Setting range | Unit | Factory setting |
|--------|-------------|--|---------------|------|-----------------|
| E/L_12 | CommDlyDist | Communication delay compenstion distance | 100 ~ 1000    | mm   | 400             |

**14) E/L\_13**

Deceleration start distance can be adjusted corresponding to speed controller characteristics and load quantity. Deceleration starts at the place calculated by deceleration start distance from inverter plus E/L\_13.

| Code   | LCD display | Parameter name                | Setting range | Unit | Factory setting |
|--------|-------------|-------------------------------|---------------|------|-----------------|
| E/L_13 | DecStartAdj | Deceleration start adjustment | -10 ~ 20      | mm   | 0               |

**15) E/L\_14**

Time taken to output traction machine Brake ON command to BRA-BRB terminal on the board after FX/RX is input.

**16) E/L\_15**

Time taken to output elevator speed command after traction machine Brake ON command is output to BRA-BRB terminal on the board after FX/RX is input.


**17) E/L\_16**

Can set the time to maintain zero speed after elevator car speed became zero speed. There is a delay time for traction machine brake to activate after FX/RX command is off, triggering brake command off. If inverter does not output stopping torque at zero speed, elevator car may move Up or Down operation depending on load quantity.

**18) E/L\_17**

Time taken to restart after stop.

| Code   | LCD display  | Parameter name           | Setting range | Unit | Factory setting |
|--------|--------------|--------------------------|---------------|------|-----------------|
| E/L_14 | PreExct Time | Pre-excitation time      | 100 ~ 10000   | msec | 300             |
| E/L_15 | Brake Time   | Brake open time          | 0 ~ 10000     | msec | 300             |
| E/L_16 | Hold Time    | Hold time                | 0 ~ 10000     | msec | 300             |
| E/L_17 | Restart Time | Wait time before Restart | 0.00 ~ 100.00 | sec  | 1.00            |




## 19) E/L\_18

## 20) E/L\_19

In FHM operation, inverter measures shield plate length and distance between inductor and shield plate edge as well as floor height of each. Whenever position sensor is triggered at each floor level, accumulated pulse counter value is saved to the memory automatically.

| Code   | LCD display  | Parameter name                              | Setting range   | Unit | Factory setting |
|--------|--------------|---|-----------------|------|-----------------|
| E/L_18 | Plate Length | Car plate length                            | E/L_19 ~ 1000.0 | mm   | 200.0           |
| E/L_19 | InductorEdge | Distance between inductor and car plate top | 0.0 ~ E/L_18    | mm   | 20.0            |



## 21) E/L\_20

Sets the car speed per minute (m/m) during FHM operation. When one of the terminal defined as manual operation is turned ON, car speed value is changed to one of E/L\_22~E/L\_24 from E/L\_21. E/L\_20 setting is used as the speed ref. for Lowest floor operation.

| Code   | LCD display   | Parameter name  | Setting range | Unit | Factory setting |
|--------|---------------|---|---------------|------|-----------------|
| E/L_20 | FHM/BFR Speed | Car speed during FHM (Floor height measurement) operation | 0.0 ~ 60.0    | m/m  | 15.0            |

## 22) E/L\_21

Displays FHM operation results. First two bits indicate the number of floor measured and the last bit shows success("1" displayed) or failure("0" displayed) of operation. For instance, when "321" is displayed after FHM operation is finished, "32" means the number of floors checked is 32 and "1" means successful operation.

| Code   | LCD display | Parameter name                | Setting range | Unit | Factory setting |
|--------|-------------|-------------------------------|---------------|------|-----------------|
| E/L_21 | FHM DATA    | Floor height measurement data | 0 ~ 321       |      | 0               |

## 23) E/L\_22

## 24) E/L\_23

## 25) E/L\_24

Speed for various modes of manual operation (maintenance, escape and FHM operation) can be set by mixing multi-function input terminals **MM0/P1** and **MM1/P2**. Codes E/L\_22 thru E/L\_24 are only displayed when E/L\_01 is set either DecelReq-D/B or DecelReq-T/B.

| Code   | LCD display | Parameter name                      | Setting range | Unit | Factory setting |
|--------|-------------|-------------------------------------|---------------|------|-----------------|
| E/L_22 | Manual Spd1 | Car speed 1 during manual operation | 0.0 ~ 60.0    | m/m  | 3.0             |
| E/L_23 | Manual Spd2 | Car speed 2 during manual operation | 0.0 ~ 60.0    | m/m  | 10.0            |
| E/L_24 | Manual Spd3 | Car speed 3 during manual operation | 0.0 ~ 60.0    | m/m  | 15.0            |

When **MM0/P1**, **MM1/P2** are set to "Man Speed-L", "Man Speed-M", respectively, car speed ref. is determined as the followings.

| MM0/P1 | MM1/P2 | Set speed          |
|--------|--------|--------------------|
| OFF    | OFF    | N/A <sup>(1)</sup> |
| ON     | OFF    | E/L_22             |
| OFF    | ON     | E/L_23             |
| ON     | ON     | E/L_24             |

(1) Decelerates to zero speed when MM0 and MM1 are Off during manual operation. N/A is displayed at a stop.

**26) E/L\_25**

**27) E/L\_26**

**28) E/L\_27**


**29) E/L\_28**

**30) E/L\_29**

**31) E/L\_30**


**32) E/L\_31**

| Code   | LCD display  | Parameter name                                  | Setting range | Unit               | Factory setting |
|--------|--------------|---|---------------|--------------------|-----------------|
| E/L_25 | MAN Accel.   | Acceleration speed during manual operation      | 0.01 ~ 5.00   | m/sec <sup>2</sup> | 0.50            |
| E/L_26 | MAN Decel.   | Deceleration speed during manual operation      | 0.01 ~ 5.00   | m/sec <sup>2</sup> | 0.50            |
| E/L_27 | ManAccStartT | Acceleration start time during manual operation | 0.01 ~ 2.00   | sec                | 0.50            |
| E/L_28 | Man AccEnd T | Acceleration end time during manual operation   | 0.01 ~ 2.00   | sec                | 0.50            |
| E/L_29 | ManDecStartT | Deceleration start time during manual operation | 0.01 ~ 2.00   | sec                | 0.50            |
| E/L_30 | Man DecEnd T | Deceleration end time during manual operation   | 0.01 ~ 2.00   | sec                | 0.50            |



When speed command is changed due to change in multi-function input state and deceleration begins (for example, 15m/m → 3m/m), set the decel condition in **E/L\_26, E/L\_29 and E/L\_30**. This will lead to S-curve deceleration. However, if FX/RX command is off while multi-function input status is maintained, linear deceleration will be performed at zero speed. It is used when faster stop is required than soft landing.

| Code   | LCD display  | Parameter name                            | Setting range | Unit | Factory setting |
|--------|--------------|---|---------------|------|-----------------|
| E/L_31 | ManZeroDec T | Deceleration time during manual operation | 0.00 ~ 2.00   | sec  | 0.00            |



### 33) E/L\_32

### 34) E/L\_33

Position controller compensates the distance at the instant when an inductor located on the the car leave the shield plate. The adjusting value depends on car speed. Max/Min value should be set for appropriate compensation. E/L\_32 value will be automatically set as initial value after FHM operation is finished.

| Code   | LCD display  | Parameter name                                  | Setting range | Unit | Factory setting |
|--------|--------------|---|---------------|------|-----------------|
| E/L_32 | DistComp.Min | Distance compensation, Minimum during operation | 0 ~ 2*E/L_18  | mm   | 0               |
| E/L_33 | DistComp.Max | Distance compensation, Maximum during operation | 0 ~ 100       | mm   | 0               |

### 35) E/L\_34

This setting value is used to compensate the current position when inductors are activated after car deceleration starts and enters a floor level with E/L\_01 set to DecelReq-D/B. This is only displayed when E/L\_01 is set to DecelReq-D/B.

| Code   | LCD display  | Parameter name                                | Setting range     | Unit | Factory setting |
|--------|--------------|---|-------------------|------|-----------------|
| E/L_34 | DistComp.Lev | Leveling distance compensation <sup>(1)</sup> | -E/L_19 ~ +E/L_19 | mm   | 0               |

**36) E/L\_35**

Sets the creep speed (car speed running at constant speed before leveling) when E/L\_01 is set to DecelReq-T/B.

| Code   | LCD display | Parameter name             | Setting range | Unit | Factory setting |
|--------|-------------|----------------------------|---------------|------|-----------------|
| E/L_35 | Creep Speed | Creep speed <sup>(2)</sup> | 1.0 ~ 60.0    | m/m  | 3.0             |

**37) E/L\_36**

Sets the creep distance when E/L\_01 is set to DecelReq-T/B.

| Code   | LCD display | Parameter name | Setting range | Unit | Factory setting |
|--------|-------------|----------------|---------------|------|-----------------|
| E/L_36 | Creep Dist. | Creep distance | 0 ~ 500       | mm   | 0               |

**38) E/L\_37****39) E/L\_38**

Set the **E/L\_37** (distance to end position control) and **E/L\_38** (time to decel to zero speed) before leveling to stop. If E/L\_37 is set to "0", deceleration is performed based on the distance until leveling and if E/L\_37 is set to other than "0", it is changed to time-based for remaining distance to reach target floor level.

| Code   | LCD display  | Parameter name   | Setting range | Unit | Factory setting |
|--------|--------------|--|---------------|------|-----------------|
| E/L_37 | D/B End Dist | Position control end and zero speed decel start distance     | 0 ~ E/L_19    | mm   | 0               |
| E/L_38 | SpdZero Time | Time to decelerate to zero speed after position control ends | 0.01 ~ 10.00  | sec  | 2.00            |



## 40) E/L\_39

ELIO board input signal is programmed as A contact (Normally OFF (Open), ON when operating (Closed)). If inductor and limit switch for forced decel are programmed as B contact (normally ON (Closed), OFF when operating (Open)), input signal should be set to "1" to inverse the signal. However, DAC is not able to operate as B contact.

| Code   | LCD display | Parameter name                  | Setting range                  | Unit | Factory setting |
|--------|-------------|---------------------------------|--------------------------------|------|-----------------|
| E/L_39 | ELIO IN Neg | ELIO input negative (inversion) | 000000000000<br>~ 111111111111 | sec  | 000000000000    |

**E/L\_39 set value is corresponding to EL-I/O input terminal (CN3) one to one and setting "1" makes the selected terminal to "B contact".**

| MSB |     |     |     |                    |                    |     |     |     |     |     | LSB                |
|-----|-----|-----|-----|--------------------|--------------------|-----|-----|-----|-----|-----|--------------------|
| I_D | I_U | DLS | ULS | RV1 <sup>(1)</sup> | RV2 <sup>(1)</sup> | SD1 | SU1 | SD2 | SU2 | DAC | RV3 <sup>(1)</sup> |

(1) Available from version 3.0 of EL-I/O option board. These are written as WD1, WD2 and ACR for version 2.0.

## 41) E/L\_40

## 42) E/L\_41

Adjust the filter time when elevator car is operating wrong due to noise interference.

| Code   | LCD display | Parameter name             | Setting range | Unit | Factory setting |
|--------|-------------|----------------------------|---------------|------|-----------------|
| E/L_40 | IND Filter  | Inductor input filter time | 0 ~ 50        | ms   | 25              |
| E/L_41 | SDS Filter  | Filter time for SDS input  | 50 ~ 500      | ms   | 250             |

## 43) E/L\_42

## 44) E/L\_43

## 45) E/L\_44

## 46) E/L\_45

When Limit switch for forced decel (SDS-U1) at the top floor is active and car speed exceeds setting in E/L\_42, car starts forced deceleration with E/L\_43 and keeps running with E/L\_44 until UP/DOWN inductors are active and stops after E/L\_45 elapses. E/L\_43 and E/L\_44 are only displayed when E/L\_42 or E/L\_47 setting is other than "0". E/L\_43, E/L\_44, E/L\_45 are applied to SDS-D2 and SDS-U2.

| Code   | LCD display  | Parameter name   | Setting range | Unit               | Factory setting |
|--------|--------------|--|---------------|--------------------|-----------------|
| E/L_42 | ForcedDecSpd | Forced deceleration starting speed during SDS-1 input    | 0.0 ~ 420.0   | m/m                | 0.0             |
| E/L_43 | ForcedDecel  | Deceleration speed during SDS-1 forced deceleration      | 0.01 ~ 5.00   | m/sec <sup>2</sup> | 1.50            |
| E/L_44 | ForcedCrpSpd | Creep speed during forced deceleration                   | 0.0 ~ 60.0    | m/m                | 3.0             |
| E/L_45 | Frcd.DecWait | Wait after zero speed arrival during forced deceleration | 0 ~ E/L_16    | msec               | 300             |

### 47) E/L\_46

### 48) E/L\_47

Defines the use of SDS-D2 and SDS-U2 and forced decel start speed. E/L\_47 will appear when E/L\_46 is set to "Yes". When this limit switch at the top floor is active and car speed exceeds setting in E/L\_46, car starts forced deceleration with E/L\_43 and keeps running with E/L\_44 until UP/DOWN inductors are active and stops after E/L\_45 elapses.

| Code   | LCD display  | Parameter name                                     | Setting range | Unit | Factory setting |
|--------|--------------|--|---------------|------|-----------------|
| E/L_46 | Use FrdDcl2  | Use SDS-2  | NO/Yes        | -    | No              |
| E/L_47 | ForcedDecSpd | Forced deceleration start speed during SDS-2 input | 0.0 ~ 420.0   | m/m  | 0.0             |

### 49) E/L\_50

When this parameter is set to 'Inductor ON', elevator car can start only when two inductors are within shield plate. When set to 'Always', car can always start regardless of inductor operation.


| Code   | LCD display  | Parameter name                                   | Setting range         | Unit | Factory setting |
|--------|--------------|--|-----------------------|------|-----------------|
| E/L_50 | HighSpdStart | Starting Condition for High speed Auto Operation | Inductor ON<br>Always | -    | Inductor ON     |

### 50) E/L\_52

### 51) E/L\_53

### 52) E/L\_54

Used for optimal start/stop (up/down) riding comfort of the elevator car during Auto operation. the optimum value can be found by repeating operation with different parameter values input.



| Code   | LCD display  | Parameter name              | Setting range | Unit               | Factory setting |
|--------|--------------|-----------------------------|---------------|--------------------|-----------------|
| E/L_52 | StartupAccel | Start-up acceleration speed | 0.01 ~ 1.00   | m/sec <sup>2</sup> | 0.00            |
| E/L_53 | StartupAccT  | Start-up acceleration time  | 0.01 ~ 5.00   | sec                | 0.01            |
| E/L_54 | StartupWait  | Start-up wait time          | 0.00 ~ 5.00   | sec                | 0.50            |

### 53) E/L\_55

Set the wait time taken for leveling/decel/stop to be completed for lowest floor operation or nearest floor operation after UP/Down inductor activates.

| Code   | LCD display  | Parameter name  | Setting range | Unit | Factory setting |
|--------|--------------|---|---------------|------|-----------------|
| E/L_55 | BFR/NFR Wait | Wait time before leveling at Lowest floor/Nearest floor | 0.00 ~ 5.00   | sec  | 0.30            |

### 54) E/L\_58 – refer to “Keypad display at elevator mode” for detail description

When CON\_02 “Application” is set to “Elevator”, the following display mode can be set. In case of “Limit S/W State”, ON/OFF state will appear according to the setting in E/L\_40.

| Code   | LCD display  | Parameter name                                | Setting range   | Unit       | Factory setting |
|--------|--------------|---|-----------------|------------|-----------------|
| E/L_58 | Display Sel. | Current car speed per min.                    | Car Speed (m/m) | m/m        | Car Speed (m/m) |
|        |              | Current car speed per sec.                    | Car Speed (m/s) | m/s        |                 |
|        |              | Motor speed                                   | Motor Speed     | rpm        |                 |
|        |              | Current car position                          | Car Position    | mm         |                 |
|        |              | Motor output torque                           | Trq Output      | %          |                 |
|        |              | Limit switch status <sup>1)</sup>             | Lmt.S/W State   | I--S--S2-- |                 |
|        |              | Tuning distance when first inductor is active | Tuning Dist     | mm         |                 |

#### 1) Limit switch status displayed

Ex) when an elevator car is located at the lowest floor level. - IND\_UP, IND\_DN, SDS1, SDS2 ON (-: OFF, : ON)

| Inductor | Down | Up | SDS1 | Down | Up | SDS2 | Down | Up |
|----------|------|----|------|------|----|------|------|----|
| I        |      |    | S    |      | -  | S2   |      | -  |

### 55) E/L\_59

Current car position can be reset to 0mm, If Yes is set, floor number on the LCD display is changed to "1".

| Code   | LCD display | Parameter name     | Setting range | Unit | Factory setting |
|--------|-------------|--------------------|---------------|------|-----------------|
| E/L_59 | Clear Posi. | Clear car position | No<br>Yes     | -    | No              |

### 56) E/L\_60

The height of each floor can be checked after FHM operation is completed.

| Code   | LCD display  | Parameter name      | Setting range | Unit  | Factory setting |
|--------|--------------|---------------------|---------------|-------|-----------------|
| E/L_60 | Show FlrPosi | Show floor position | 1 ~ E/L_02    | FLOOR | 1               |